

	<u>Music Mute</u>	<u>Priority Line Level Input</u>	<u>Priority Mic Input</u>
DCM1 & DCM1e	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact (Software selectable) Instant Attack <u>Option:</u> Any single input can be selected to be active during Music Mute. If Line Input; Level can be fixed. 1-12sec Release (Software Selectable)	Any single Line Level Input can be set to Priority on any Zone VOX Trigger Instant Attack 1-12sec HOLD (Software Selectable) 1-12sec Release (Software Selectable)	Any combination of mics available to any zone. VOX Trigger Instant Attack 1-12sec HOLD (Software Selectable) 1-12sec Release (Software Selectable)
Z4Z8MK4	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 3sec Release	Line Level Input 6 can be set to Priority This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 and 2 On or Off in any zone Vox trigger Instant Attack 3 Sec Release
CX163	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5 sec Release	Line Level Input 6 can be set to Priority on Zone 1 This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 Vox trigger, Access trigger or OFF Instant Attack 3 Sec Release
CX261	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5sec Release	Line Level Input 6 can be set to Priority This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 and 2 On or Off Microphone 1 and 2 Vox or access. Microphone 1 priority over microphone 2 Instant Attack 3 Sec Release
CX263	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5sec Release	Line Level Input 6 can be set to Priority on any Zone This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 and 2 On or Off in any zone Microphone 1 Vox or access, microphone 2 Vox. Microphone 1 priority over microphone 2 Instant Attack 3 Sec Release
36-50	2Pin 5mm Phoenix Connector NO Voltage Free Contact Instant Attack 5 sec Release	Line Level Input 6 can be set to Priority on any Zone This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 in any zone Vox trigger, Access trigger or OFF Instant Attack 3 Sec Release
46-80	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5sec Release	Line Level Input 6 can be set to Priority on Zone 1 or All Zones This is a VOX Trigger Instant Attack 12sec Release	Microphone 1 and 2 On or Off in all zones Microphone 1 Vox or access, microphone 2 Vox. Microphone 1 priority over microphone 2 Instant Attack 3 Sec Release
46-50	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5sec Release	Line Level Input 6 can be set to Priority on Zone 1 This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 and 2 On or Off in all zones Microphone 1 Vox or access, microphone 2 Vox. Microphone 1 priority over microphone 2 Instant Attack 3 Sec Release
46-120	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5sec Release	Line Level Input 6 can be set to Priority on Zone 1 This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 and 2 over music On or Off in all zones Microphone 1 over 2 disabled by track cut
MA60	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5 Sec Release	Line Level Input 4 can be set to Priority This is a VOX Trigger (with a HOLD Option) Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1 Vox trigger, Access trigger or OFF Instant Attack 3 Sec Release
MA40 Series	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5 Sec Release	Line Level Input 1 can be set to Priority This is a VOX Trigger Instant Attack 6 sec Release	Microphone 1 Vox trigger, Access trigger or OFF Instant Attack 3 Sec Release
MA80 Series	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5 Sec Release	Line Level Input 1 can be set to Priority This is a VOX Trigger Instant Attack 6 sec Release	Microphone 1 Vox trigger, Access trigger or OFF Instant Attack 3 Sec Release
MPASeries	2Pin 5mm Phoenix Connector NO or NC Voltage Free Contact Instant Attack 5 Sec Release	Line Level Input 6 can be set to Priority This is a VOX Trigger Instant Attack 3, 6 or 12sec Release (Jumper Selectable)	Microphone 1, 2, 3 and 4 On or Off Microphone 1 Vox or access, microphone 2, 3, and 4 Vox. Microphone 1 priority over microphone 2, 3 and 4 Instant Attack 3 Sec Release