

Cloud MA60 & MA60_{MEDIA} Jumper Settings



Ref	Description	Default	Location	Notes
J1	Mic input phantom power	OFF	Main	ON/OFF
J2	Mic input transformer isolation	OFF	Main	ON/OFF
J3			Main	
J4			Main	
J5	Mic Access Bypass	ON	Main	ON/OFF
J6	MOH/Utility music source	SW	Rear	SW/L1/L2/L3/L4/MP3
J7	100 Hz mic high-pass filter	ON	Main	ON/OFF
J8	EQ card bypass	ON	Main	ON/OFF
J9	Force front panel source selection	SW	Rear	FR/SW
J10	Mic EQ bypass	ON	Rear	ON/OFF
J11	L4 Priority Release Time	3 s	Rear	3 s/6 s/12 s (no jumper)
J12A	L4 Priority	OFF	Rear	ON/OFF
J12B			Rear	
J13	65 Hz high-pass filter	OFF	Main	ON/OFF
J14	Mic priority	AVO	Main	AVO/SW/OFF
J15	Music Mute contact type	NO	Main	NO/NC

General Notes:

Cloud Electronics Limited
 140 Staniforth Road, Sheffield, S9 3HF. England
 Telephone: +44 (0)114 244 7051 Fax: +44 (0)114 242 5462
 Web: www.cloud.co.uk E-mail: info@cloud.co.uk

Cloud Electronics USA
 2065 Sidewinder Drive, Suite 200, Park City,
 Utah 84060. United States of America.
 Toll Free: 0855 810 0161
 Web: www.cloudusa.pro E-mail: sales@cloudusa.pro